





At a glance First look Hot topics

Menu

Back

More

Next

First look

Let's get started! We'll guide you through startup and tell you a bit about your phone's features.

Note: software updates happen frequently, so your phone may look a little different.



Tips & tricks

- Start: ready to start? See "Start".
- Hot topics: just want a quick list of what your phone can do? See "Hot topics".
- Help: all your questions about your new phone answered right on your phone. Tap Apps (....) → ? Help. Want even more? See "Get help & more".

Note: certain apps and features may not be available in all countries.

This product meets the applicable national or international RF exposure guidance (SAR guideline) when used normally against your head or, when worn or carried, at a distance of 1.5 cm from the body. The SAR guideline includes a considerable safety margin designed to ensure the safety of all persons, regardless of age and health.

Caution: before using your phone, please read the safety, regulatory and legal information at www.motorola.com/mymotoxplay.



At a glance

More

Next

|>>

At a glance First look Hot topics

Menu

Back

<<

Hot topics

Check out what your phone can do.

Find these fast: Wi-Fi, aeroplane mode, flashlight and more.	"Quick settings"
Choose new wallpaper, sounds and more.	"Redecorate your Home screen"
More megapixels for clearer photos.	"Take photos"
Access the Internet.	"Browse"
Browse, shop and download apps.	"Download apps"
Keep your info safe. Set up your password and more.	"Protect"
Never get lost again.	"Locate & navigate"
Save data charges. Use Wi-Fi.	"Wi-Fi networks"
Stuck? Confused?	"Help & more"



let's get up & running

Start

Start Put in the cards & power on Motorola Shells Protective bumper Battery life Sign in Old phone to new phone

Menu

Back


More

Next

Put in the cards & power on

Put in the nano SIM and optional microSD cards.

Caution: make sure you use the correct size SIM cards, don't cut the SIM card, and don't use adapters with your SIM cards. Note: in some countries, you can use a second SIM card. Tip: to make the screen sleep or wake up, press the Power button. To turn your phone on or off, press and hold it.



Dual SIM phone settings

With a dual SIM phone, you can use one or two nano SIM cards. If there's only one SIM in the phone, it's ready to use. With two cards inserted, you can use either or both.

To set up your phone to use two SIM cards, insert both cards, turn on your phone and follow the prompts. To finish dual SIM setup, drag down the status bar at the top of the Home screen and tap **Welcome to your dual SIM**.

Tip: with two SIM cards, you see **A** at the top of your Home screen.



Start Put in the cards & power on Motorola Shells Protective bumper Battery life Sign in Old phone to new phone

Dual SIM calling

You can choose which SIM to use for outgoing calls. Your phone automatically prompts you in a notification to enable this feature. Or, to enable it any time, tap Apps 📰

→ i Settings → SIM cards → Automatic SIM selection.

Note: To quickly open **Settings**, swipe down the status bar or the lock screen with two fingers and tap **\$**.

Motorola Shells

You can change the back cover for a new look with Motorola Shells.

Note: Motorola Shells are sold separately and availability varies by country.



Protective bumper

Your phone may have come with a bumper to protect it without covering its premium design. Simply attach the bumper for extra protection.

Caution: don't use tools to remove the protective bumper — doing so may damage your phone.

Put on the protective bumper.

Put the top of the phone inside the protective bumper. Press the rest of the phone into the bumper.





Back





Start

Start Put in the cards & power on Motorola Shells Protective bumper Battery life Sign in Old phone to new phone

Battery life

Your phone is like a small computer that processes tons of information and apps at lightning-fast speed. Depending on what you use, that can take a lot of power.

To see what's using up battery power, tap Apps i \Rightarrow $\textcircled{settings} \Rightarrow$ **Battery**.

To turn on Battery saver, tap Apps $\textcircled{iii} \rightarrow \textcircled{iii}$ Settings \rightarrow Battery, then tap Menu $\textcircled{i} \rightarrow$ Battery saver mode.

Note: To quickly open **Settings**, swipe down the status bar or the lock screen with two fingers and tap **\$**.

Tips & tricks

To save even more battery life between charges, you could reduce:

- Wi-Fi and Bluetooth use: tap Apps (iii) → ⁽ⁱ⁾ Settings, then tap Wi-Fi or Bluetooth to turn them off when you don't need them.
- Display brightness: tap Apps (iii) → iii Settings → Display
 → Brightness level → (slide dimmer setting left). Make sure
 Adaptive brightness is also turned on.
- Display timeout delay: tap Apps (iii) → (iii) → Sleep → (shorter setting).
- Widgets that stream information to your Home screen, like news or weather.
- Unused online accounts that you registered: tap Apps 📖

→ ③ Settings → Accounts. Tap the account you want to remove. Tap it again, then tap Menu → Remove account.

• Recording or watching videos, listening to music or taking pictures.

Warning: don't try to remove or replace the battery yourself — doing so may damage the battery and may cause burning and injury. If your phone becomes unresponsive, try a reboot — press and hold the Power button until the screen goes dark, and your phone restarts.








Start Put in the cards & power on Motorola Shells Protective bumper Battery life Sign in Old phone to new phone

Sign in

Just follow the screen prompts to get started.

If you use Gmail[™], you already have a Google[™] account — if not, you can create an account during setup. Signing in to your Google account lets you access, sync and back up your stuff. See your Google apps, contacts, calendar, photos and more.



Tips & tricks

- Wi-Fi network: for faster Internet access or to conserve mobile data use, swipe the status bar down with two fingers, tap tap and then tap Wi-Fi. There's more in "Wi-Fi networks".
- Accounts: to add, edit or delete accounts, tap Apps (...) → ③ Settings → Accounts, then tap + Add account. To set up email accounts, see "Email".

For help with your Google account, visit **www.google.com/accounts**.

• Contacts: to get your contacts from your old phone, you have options. If your old phone was also Android[™] and you used the Android Backup and restore feature, your contacts automatically appear on your new phone. Otherwise, use the Motorola Migrate app in "Old phone to new phone". Or, visit www.motorola.com/transfercontacts.

Note: this phone supports apps and services that may use a lot of data, so make sure your data plan meets your needs. Contact your service provider for details.







Start Put in the cards & power on Motorola Shells Protective bumper Battery life Sign in Old phone to new phone

Menu Seck




More

Old phone to new phone

Copying your personal stuff from your old phone to your new phone is easy. If you did not migrate during setup, you can do it any time.

Note: if your old phone is an Android[™] phone, download the Motorola Migrate app on Google Play[™] on your old phone before you get started.

Find it: on your new phone, tap Apps (...) → **Migrate**



Tips & tricks

- While you're migrating, you can keep using your phone.
- Signing in to your Google account copies your apps if they are backed up to the cloud.
- For iPhones, you can migrate contacts and calendar events only from the iCloud.
- For phones that support copying music, not all music can be copied. (If you want to know more, you can search online to learn about digital rights management or DRM-protected files.)
- Older phones that are not Android or iPhone devices must have Bluetooth capability.



you have quick access

Home screen & apps **Quick start: Home screen & apps** Help & more Search Status & notifications Volume & interruptions **Discover your Moto apps** Download apps Take care of your apps Update your phone



Quick start: Home screen & apps

phone. From here, you can explore apps and more.

your Home screen, or tap 🖢 to search by voice.

• Open app list: to see your apps, tap Apps (...).

The Home screen is what you see when you first turn on your

• Search: type text in the Google Search box at the top of

Swipe down with one finger for notifications or with two fingers for profiles and settings.

Search by typing or say "OK, Google".

Touch and hold an empty spot to change widgets. wallpaper and more.

Tap Apps (:::)to see all your apps.

Tips & tricks

- Widgets: to put widgets like a clock, interactive calendar and more on your Home screen, touch and hold an empty spot on the Home screen, then tap WIDGETS.
- Pages: to add a page, drag an app to the right side of the screen until you see a white bar. You can add multiple pages. To show other pages of shortcuts and widgets, swipe the Home screen left.
- Google Now[™]: touch and hold Home O, then flick up to the Google icon 🖾. After setup, you can access it by swiping right from the Home screen.
- Settings: to guickly open settings, swipe the status bar down with two fingers. To open more settings, tap 🗴.
- Shortcuts: tap Apps (iii), touch and hold the app, then drag it to one of your Home screen pages. To see all your apps, tap Apps (iii) and swipe to the left.
- Apps: to uninstall apps, tap Apps (...), touch and hold an app, then drag it to Uninstall. (You can't uninstall some apps.)

To remove an app from a Home screen page, touch and hold the app, then drag it to **Remove**. The app isn't removed from your phone, just the Home screen.

 Customisation: for more about changing your Home screen, see "Redecorate your Home screen".

Menu

More







Home screen & apps Quick start: Home screen & apps Help & more Search Status & notifications Volume & interruptions Discover your Moto apps Download apps Take care of your apps Update your phone

Menu

Back

More 🕥

Help & more

Watch a tutorial. Read a how-to. Talk to someone. Find out anything about your phone.

Find it: Apps → 💡 Help

⊿ ∎11:35	
≡ Home Q 🌣	Let us suggest a few
etting started	changes for you.
irst things first	Watch tutorials, read
New to Android?	how-tos and more.
Show me how (step by step)	
Explore	
Learn about Motorola features	
Personalise your device	
Discover apps	
Optimise battery life	
BROWSE ALL HELP	
Chat Call	Need a real-life, actual human? Chat or call us.

Search

At the top of the Home screen, tap the Google Search box for a text search or tap \clubsuit to search by voice.

When you type, suggestions appear below the search field:

- To search for a suggestion, tap it.

Tip: to close the keyboard, tap ∇ .

Status & notifications

At the top of the screen, icons on the left notify you about new messages or events. If you don't know what an icon means, swipe the status bar down for details.

Tip: getting too many notifications? Touch and hold a notification to see which app is sending them to you. Then you can turn them off.



Tip: to quickly change common settings, swipe the status bar down with two fingers. For more, see "**Quick settings**".

More



Home screen & apps **Quick start: Home screen & apps** Help & more Search Status & notifications Volume & interruptions **Discover your Moto apps Download** apps Take care of your apps Update your phone

Menu

Icons at the top right of your screen tell you about phone status:

Network strength	🛇 No sound
�∕▼Wi-Fi in range/connected	'I <mark>I</mark> I' Vibrate
℁ Bluetooth on	★ Priority
🛧 Aeroplane mode	🕜 Alarm set
💈 / 📋 Battery charging/full	🔔 Warning

Note: apps you download on Google Play™ might show other icons in the status bar to alert you to specific events.

Volume & interruptions

Press the side volume button up or down to select a volume from high to vibrate $|\Box|$.



Also, tap one of these options for more settings:

- All: receive all interruptions and alarms.
- Priority: tap **★**, then tap **\$** to select which interruptions to receive. You will always hear alarms. Set when you want to be in this mode, or choose indefinitely.
- None: turn off all sounds and alarms. Override sound settings from other apps. Set how long to stay in this mode, or choose indefinitely.

Discover your Moto apps

Moto apps can simplify life and help you out. Just follow the prompts to find out more.

Find it: Apps (...) > 🚱 Moto

- Assist: set your phone to adapt to what you're doing, where you are. For example, keep alarms guiet at night while you're sleeping.
- Actions: learn how to open your camera with two twists of your wrist using Quick Capture. See "Photos & videos" for more details.
- Voice: set your custom launch phrase and control your Moto X with your voice.
- Display: see messages, calls and other notifications even if your phone is asleep.




Home screen & apps Quick start: Home screen & apps Help & more Search Status & notifications Volume & interruptions Discover your Moto apps Download apps Take care of your apps Update your phone

Menu

More

Note: your phone may not have all features.



Tip: want to hide sensitive or private notifications? Tap Apps $(:::) \rightarrow \bigcirc$ **Moto** \rightarrow **Display** and set which apps can show notifications and how much to display.

Download apps

Google Play™

Get music, films, books, apps, games and more.

Find it: Apps $\textcircled{m} \rightarrow \textcircled{p}$ Play Store

• Find: to search for apps, tap \mathbb{Q} .

- **Download:** to download an app you found, tap it to see details, then tap **INSTALL**, or the price.
- Share: to share an app you find on Google Play, tap it to see details and then tap <.
- Use a computer: to find and manage apps from any computer, go to http://play.google.com using your Google account and password.

There, you can browse apps on the big screen, manage your apps across multiple devices (such as a phone or tablet) and even set new apps to download to your devices.

- Enjoy music: you can also use Google Play to download music. See "Play Music".
- Get help: to get help and more, tap =

Apps from the web

You can get apps from other online app stores using your browser.

Tip: choose your apps and updates carefully, as some may impact your phone's performance — see "**Choose carefully**".

Note: when installing an app, make sure you read the alerts that tell you what information the app will access. If you don't want the app to access this information, cancel the installation.

To let your phone install apps that are not on Google Play, tap Apps (....) → 🏟 Settings → Security and tick Unknown sources.



Home screen & apps Quick start: Home screen & apps Help & more Search Status & notifications Volume & interruptions Discover your Moto apps Download apps Take care of your apps Update your phone

Menu



For information about downloading files from your browser, see "**Downloads**".

Choose carefully

Here are a few tips:

- To help prevent spyware, phishing or viruses, use apps from trusted sites, such as Google Play.
- In Google Play, check the app's ratings and comments before installing.
- If you doubt the safety of an app, don't install it.
- Apps use up memory, data, battery and processing power

 some more than others. If you're not happy with how
 much memory, data, battery or processing power it's using,
 uninstall it.
- Monitor children's access to apps to help prevent exposure to inappropriate content.
- Certain apps may not provide completely accurate information. Take care, especially when it comes to personal health.

Take care of your apps

Find it: tap Apps iii, then swipe left to scroll through apps To close the apps screen, tap Home \bigcirc or Back \triangleleft .

• Uninstall apps: to remove an app from a Home screen page, touch and hold the app, then drag it to **Remove**. The app isn't removed from your phone, just the Home screen. Tap Apps (iii) → 🏟 Settings → Apps. Swipe left to ALL, tap an app, then tap **DISABLE** or **UNINSTALL** in the top right (if available).

Tip: to quickly show app details, tap Apps (:::), touch and hold an app, then drag it to **App info**.

DISABLE removes the app from your menu. To **ENABLE** it, reopen this window and tap **ENABLE** (disabled apps are at the bottom of the list).

If an app locks up your phone as soon as you turn it on, restart in safe mode: turn off your phone, then turn it back on — when you see the "Motorola" logo during power-up, press and hold both volume buttons until you see the Home screen, with **Safe mode** in the bottom left. Then, try removing the app.

- Reinstall apps: to reinstall apps from Google Play, tap Apps (iii) → Play Store, then tap → My apps. The apps you downloaded are listed and available for download.
- See or clear app details: tap Apps (iii) → 🏟 Settings → Apps. Swipe left or right to see the list of DOWNLOADED, RUNNING or ALL apps, then tap an app in the list to see its details and storage usage. You can tap CLEAR DATA, CLEAR CACHE or other options.

Tip: to quickly show app details, tap Apps (...), touch and hold an app, then drag it to **App info**.

• See app data usage: to see which apps are using the most data, tap Apps :::: → 🏟 Settings → Data usage. For more, see "Data usage".



Home screen & apps Quick start: Home screen & apps Help & more Search Status & notifications Volume & interruptions Discover your Moto apps Download apps Take care of your apps Update your phone

Update your phone

Use your phone or computer to check, download and install phone software updates:

• Using your phone:

if your phone notifies you about an update, follow the instructions to download and install it.

To manually check for updates, tap Apps $(iii) \rightarrow$ To **Settings** \rightarrow **About phone** \rightarrow **System updates**.

Your phone downloads updates over your Wi-Fi connection (if available) or mobile network. We recommend that you download updates over a Wi-Fi connection. Remember, these updates can be quite large (25 MB or more) and may not be available in all countries. If the mobile network updates are not available in your country, update using a computer.

Note: when updating your phone, make sure you have enough battery power to complete the update.

• Using your computer:

on your computer, go to www.motorola.com/update.

BB Menu





how it acts & looks

Control & customise Quick start: control & customise Controls and gestures On. off. lock & unlock Customise sounds and appearance **Redecorate vour Home screen Quick settings** Profiles Accessibility

Quick start: control & customise

Take control of your phone:

• Touch, press and speak: learn phone gestures and commands. See "Controls and gestures".

11:35

0

• Change your sounds and more: to put widgets like a clock, interactive calendar and more on your Home screen, see "Customise sounds and appearance".

Swipe down with two fingers to see guick settings. Swipe down with one finger to see notification:

- Touch and hold an empty spot to change wallpaper.
- Tap a shortcut to open. Touch and hold to move or delete
- Drag shortcuts on top of each other to create a folder.

Tips & tricks

- Speak: tap U in a search window, or U on a keyboard.
- Add a Home screen page: drag an icon to the right side of the Home screen until you see a white bar. You can add multiple pages.
- Quick settings: to change Wi-Fi, Bluetooth, Aeroplane mode and other settings, swipe the status bar down with two fingers. For even more settings, tap 🗘 Settings.
- Can't find a setting? Tap Apps $(iii) \rightarrow iii$ Settings $\rightarrow Q$.

Controls and gestures

Touch

Find your way around:

- Tap: choose an icon or option.
- · Touch and hold: to see more options.
- Drag: move items on the Home screen.
- Swipe: scroll through lists or between screens.
- Pinch or double tap: zoom in and out on websites, photos and maps.
- Twist: twist a map with two fingers to rotate it, and pull two fingers down to tilt it.
- Back: tap Back < to go to the previous screen.
- Home: tap Home O to return to the Home screen.
- Overview: tap Overview 🗖 to see your recent apps (or browser tabs) and tap an app to reopen it. To remove an app

Menu Back







Control & customise Quick start: control & customise Controls and gestures On, off, lock & unlock Customise sounds and appearance Redecorate your Home screen Quick settings Profiles Accessibility from the list, swipe it left or right. To scroll the list, swipe up or down.

Tip: you don't need to remove apps from Overview for your phone to run efficiently.

- Menus: when i or = appears on a screen, you can tap it to open options for the current screen.
- Close keyboard: to close a touchscreen keyboard, tap ${f
 abla}$.
- **Reboot:** to reboot your phone, press and hold the Power button until the screen goes dark and your phone restarts.

Press

Power button

Your power button helps in a few ways:

- **Power off:** press and hold the Power button to choose **Power off**.
- **Sleep:** to conserve battery power, prevent accidental touches or when you want to wipe smudges off your touchscreen, put the touchscreen to sleep by pressing the Power button.
- Wake up: press the Power button again.

Tip: to add security to your phone, see "Protect".

Volume buttons

Your volume buttons help in a few ways:

- **Ringer volume:** press the buttons when your phone is ringing to silence it.
- Earpiece volume: press the buttons during a call.
- **Music/video volume:** press the buttons during a song or video.

Tip: for more on volume control, see "Volume & interruptions".

Speak

Just tell your phone what you want.

Tip: speak naturally but clearly, like using a speakerphone.

• Search: tap I on the Home screen to search by voice, or say, "OK Google" to speak your search.

To change your voice input and text-to-speech settings, tap Apps $\textcircled{\begin{subarray}{c} \end{subarray}} \Rightarrow \textcircled{\begin{subarray}{c} \end{subarray}} \end{subarray} \end{subarr$

• Dialling and commands: tap \oint . To dial, say "Call" and then a contact name or phone number. Or, say a command like "Send text", "Go to" an app or "Help" for voice command help.

Tip: if a contact has more than one number, you can say which number to call. For example, "Call Joe Black Mobile" or "Call Suzi Smith Work".












Control & customise Quick start: control & customise Controls and gestures On, off, lock & unlock Customise sounds and appearance Redecorate your Home screen Quick settings Profiles Accessibility • Text entry: on a touchscreen keyboard, tap ψ , then speak your message or search text. You can also say punctuation.

Tip: to make your phone read out loud, see "TalkBack".

On, off, lock $\& \, unlock$

Your touchscreen is on when you need it and off when you don't. To turn the screen on, press the Power button.



- Screen off and on: press the Power button to turn the screen off and on.
- Screen lock: to unlock the screen, tap ♠ and drag up. To use a password, pattern or PIN security to unlock your screen, tap Apps (:::) → I Security → Screen lock (see "Screen lock").

• Notifications: double tap a notification to open it. You'll be prompted to enter your passcode.

Tip: choose what app notifications to hear or display.Hear: tap Apps (i) \Rightarrow (o) **Settings** \Rightarrow **Sound & notification** \Rightarrow **App notifications**, then tap an app.Display: tap Apps (i) \Rightarrow (o) **Settings** \Rightarrow **Display** \Rightarrow **Screen notifications**.

• Owner info: to add a message to your lock screen, tap Apps (:::) → ③ Settings → Security → Owner info. To set your message, just tap Back ◀.

Tip: don't put your mobile number as your contact info unless you can access your voicemail from another device.

Screen timeout: to change your timeout (screen locks automatically), tap Apps (...) → Implies → Display
 → Sleep.

Customise sounds and appearance

Customise your phone's sounds and appearance:

- Ringtone and notifications: tap Apps (iii) → ⁽/₁) Settings
 → Sound & notification.
- Vibrate or silent: to make your phone vibrate for incoming calls, tap Apps (iii) → (iii) → (iiiii) → Sound & notification → Also vibrate for calls. To turn off ringtones for incoming calls, tap Apps (iii) → (iii) → (iiii) → Sound & notification → Phone ringtone → None.
- Ringtone for a contact: to set a personal ringtone for a contact, tap Apps (...) → Contacts and tap the contact. Tap , then tap Menu → Set ringtone.







Control & customise Quick start: control & customise Controls and gestures On, off, lock & unlock Customise sounds and appearance Redecorate your Home screen Quick settings Profiles Accessibility

Menu



- Message alert: to change your message notification settings, tap Apps (...) → I Messaging → Menu → Settings, and select Notifications.
- Display settings: to change brightness, animation and other display settings, tap Apps (...) → 🎲 Settings → Display.
- **Rotate:** in many apps, the touchscreen switches from portrait to landscape when you rotate your phone. To turn this on or off, swipe down the status bar with two fingers and tap **Auto-rotate**.
- Wallpaper: to change your wallpaper, touch and hold an empty spot on your Home screen. For more, see "Redecorate your Home screen".
- Language and region: to set your menu language and region, tap Apps (...) → 🏟 Settings → Language & input → Language.

Redecorate your Home screen

For quick access to your favourite things, customise your Home screen the way you want.

- Change wallpaper: touch and hold an empty spot on your Home screen and tap WALLPAPER.
- Add a Home screen page: drag an app to the right side of the Home screen until you see a white bar. You can add multiple pages.
- Add shortcuts: tap Apps (:::), touch and hold the app, then drag it to one of your Home screen pages. To see all your apps, tap Apps (:::) and swipe to the left.

- Create shortcut folders: drag one shortcut onto another. Add more shortcuts by dragging them onto the first shortcut. To name the folder, tap it, tap the name and type a new name.
- Add widgets: to put widgets like a clock, interactive calendar and more on your Home screen, touch and hold an empty spot on the Home screen. Then tap **WIDGETS**.
- **Resize widgets:** you can resize some widgets touch and hold a widget until you feel a vibration, then release. Drag the white circles at the edges to resize.
- Move or delete widgets and shortcuts: touch and hold a widget or shortcut until you feel a vibration or see the icon expand if vibrate isn't on. Then drag it to another spot, another page or **Remove**.

Note: removing a shortcut from your Home screen doesn't uninstall the app from your phone.

Quick settings

For quick access to **Wi-Fi**, **Bluetooth**, **Brightness**, **Aeroplane mode** and other settings, swipe down the status bar or the lock screen with two fingers. For even more settings, tap 🗘 .

Need help finding this screen? See "Status & notifications".



Control & customise Quick start: control & customise Controls and gestures On, off, lock & unlock Customise sounds and appearance Redecorate your Home screen Quick settings Profiles Accessibility

BB Menu



Note: your quick settings may look a little different.



Tip: your phone has a flashlight that you can turn on and off from this screen.

Profiles

You can share your device with others by adding a user. Users will have their own space on the device for custom Home screens, accounts, apps, personalised settings and more.

Add & switch users

Note: only the phone's owner can add a user.

Swipe down the status bar with two fingers and tap Profile elements. Follow the prompts to add a new user.

To switch users, swipe down the status bar with two fingers and tap Profile (3). Tap a user name.

Note: for a temporary user, use the **Guest** profile, which has limited access to your phone's features and apps. Guests won't have access to your personal information.

Change or delete users

Tap Apps $\textcircled{m} \rightarrow \textcircled{m}$ Settings \rightarrow Users, then tap \clubsuit next to a user's name.

Accessibility

See, hear, speak, feel and use. Accessibility features are there for everyone, helping to make things easier.

Find it: Apps (→) ★ Settings → Accessibility

Note: for general information, accessories and more, visit www.motorola.com/accessibility.

Voice recognition

Just tell your phone what you'd like to do — dial, browse, search, send a text and more. Give it a go — say the prompt to ask your phone a question. Tap \clubsuit at the top of the Home screen for voice search.

TalkBack

Use TalkBack to read your screen out loud — your navigation, your selections, even your books.

To turn on TalkBack, tap Apps $\textcircled{m} \Rightarrow \textcircled{Settings} \Rightarrow Accessibility \Rightarrow TalkBack, then tap the switch to turn it on.$



Control & customise Quick start: control & customise Controls and gestures On, off, lock & unlock Customise sounds and appearance Redecorate your Home screen Quick settings Profiles Accessibility **Note:** you might need to download text-to-speech software (data charges may apply).

To use TalkBack:

- Menus and screens: tap an item in a menu or screen. Your phone speaks the name.
- Dialler and text entry: start typing. Your phone speaks each number or letter.
- **Notifications:** drag the status bar down. Your phone speaks all of the notifications.
- **Books and more:** open a book, file, message and more. Your phone reads the text out loud (app-dependent).
- **Browsers:** enable webpages in your browser to be read out loud. Move between pages, paragraphs, lines, words or characters.

Tip: navigate through your apps and menus to hear how voice readouts work on your phone.

Tip: if Explore by touch is on, swipe down then right to open the global context menu, then use the menu to pause TalkBack.

To turn off TalkBack, tap Apps $\textcircled{iii} \Rightarrow \textcircled{o}$ Settings \Rightarrow Accessibility \Rightarrow TalkBack, then tap the switch to turn it off.

Explore by touch

Use Explore by touch to expand TalkBack and have your touches read out loud as you move your finger around the screen.

To turn on Explore by touch when TalkBack is active, tap $Apps (iii) \Rightarrow _{iii} Settings \Rightarrow Accessibility \Rightarrow TalkBack \Rightarrow SETTINGS$ \Rightarrow Explore by touch.

Tip: when you turn on TalkBack for the first time, your phone asks if you want to **Enable Explore by touch?** Tap **OK** to turn it on.

Explore by touch changes your phone's touch gestures so the location of your touches can be read out loud.

- **Tap** something on the screen to hear a description or text readout.
- **Double tap** anywhere on the screen to open or activate the last touched item.
- **Swipe** using two fingers to scroll through lists or between screens.

Shortcut gestures let you navigate your phone with simple swipe gestures (for example, swipe up then left in a single motion to go to the Home screen). To see or change these shortcuts, tap Apps (...) → (2) Settings → Accessibility → TalkBack → SETTINGS → Manage gestures.

Note: the way these gestures are interpreted is specific to TalkBack. Other accessibility services may use the same gestures for different actions.

To learn more about navigating your phone with Explore by touch, tap Apps (....) → 🏟 Settings → Accessibility → TalkBack → SETTINGS → Launch "Explore by touch" tutorial.







Control & customise Quick start: control & customise Controls and gestures On, off, lock & unlock Customise sounds and appearance Redecorate your Home screen Quick settings Profiles Accessibility

B Menu



lore 💽 lext >> To turn off Explore by touch when TalkBack is active, tap Apps (....) → 🏟 Settings → Accessibility → TalkBack → SETTINGS, and untick Explore by touch.

Braille

Combine your Braille display with TalkBack for braille and speech feedback.

- Download the Braille Back app on Google Play (tap Apps (iii) → p Play Store) and install it on your phone.
- **2** Tap Apps $\textcircled{\begin{subarray}{c} \Rightarrow & & \\ \hline \begin{subarray}{c} \Rightarrow & & \\ \hline \begin{subarray}{c}$
- **3** Turn on your Braille display and put it in Bluetooth pairing mode.
- 4 On your phone, tap Apps (iii) → 🏟 Settings → Bluetooth, then tap the Bluetooth switch to turn it on and scan.
- **5** Tap the name of your Braille display to pair it with the phone.

Accessibility shortcut

Use simple gestures to quickly activate TalkBack and other accessibility features on your phone. For more information, tap Apps $\textcircled{\begin{tabular}{ll} \label{eq:accessibility} Use a simple accessibility \label{eq:accessibility} \label{eq:accessi$

Caller ID

When you want to hear who's calling:

- Read out loud: have your caller announced tap Apps ::::
 →
 Settings → Accessibility → TalkBack → SETTINGS
 - \rightarrow Speak Caller ID.

Volume & vibrate

Find it: Apps $\textcircled{m} \rightarrow \textcircled{a}$ Settings \rightarrow Sound & notification

- Opens sliders that let you set different volumes for your music or videos, ringtone, text or email notifications and alarms.
- Also vibrate for calls: determines whether your phone vibrates for incoming calls (even if the ringer is silent).

Tip: for more on volume control, see "Volume & interruptions".

Zoom

Get a closer look.

• **Pinch to zoom:** pinch to zoom on maps, web pages and photos. To zoom in, tap the screen with two fingers and then drag them apart. To zoom out, drag your fingers together.

Tip: to zoom in, you can also double tap.

- Screen magnification: triple tap the screen for full screen magnification, or triple tap and hold to temporarily magnify. Tap Apps (iii) → ^(A) Settings → Accessibility → Magnification gestures.
- Big text: show bigger text throughout your phone. Tap Apps (...) → 🏟 Settings → Accessibility → Large text.

Tip: or tap Apps (iii) \rightarrow (**iii**) **Settings** \rightarrow **Display** \rightarrow **Font size** \rightarrow **Huge**.



Control & customise Quick start: control & customise Controls and gestures On, off, lock & unlock Customise sounds and appearance Redecorate your Home screen Quick settings Profiles Accessibility

- High contrast text: show higher contrast text throughout your phone. Tap Apps (:::) → Implies Accessibility
 → High contrast text.
- Browser: choose text scaling and other accessibility settings for your browser. Tap Apps (...) → O Chrome → Menu → Settings → Accessibility.

Tip: use **Force enable zoom** to allow zooming on all webpages.

Display brightness

Your phone automatically adjusts the screen brightness when you're in bright or dark places. But you can set your own brightness level instead:

swipe down the status bar with two fingers and slide the bar to adjust.

Note: setting brightness to a high level decreases your phone's battery life.

Touchscreen & keys

To hear or feel when you tap the screen, tap Apps $\textcircled{\label{eq:screen}}$

- \Rightarrow 🔯 Settings \Rightarrow Sound & notification \Rightarrow Other sounds:
- **Dial pad:** to hear a tone when you dial a number, select **Dial pad tones**.
- Screen lock: to hear a click when you lock or unlock the screen, select Screen lock sound.
- Touchscreen: to hear a click when you tap something on the screen, select Touch sounds.

• Keys: to feel a vibration when you tap the keyboard, select Vibrate on touch.

Messages

To make text entry even easier, use features like auto-capitalisation, auto-correction and more. Tap Apps (:::) → ③ Settings → Language & input, then tap a keyboard type. Of course, if you don't want to type at all, use your voice. Tap ↓ on the touchscreen keyboard.

TTY

You can use your phone in TTY mode with standard teletype machines. Tap **C** Phone \rightarrow Menu \Rightarrow Settings \rightarrow Calls \rightarrow TTY mode and select the mode you need:

- TTY Full: type and read text on your TTY device.
- **TTY HCO**: Hearing-Carry-Over type text on your TTY device and listen to voice replies on your phone's speaker.
- **TTY VCO**: Voice-Carry-Over speak into your phone and read text replies on your TTY device.

Note: you'll need a cable/adapter to connect your TTY device to the headset jack on your phone.

Refer to your TTY device guide for mode and usage information.

Apps

Google Play has something for everyone, and many apps provide useful accessibility features.

Find it: Apps (→) Play Store








Calls when you need to talk


Calls **Quick start: calls** Make calls Answer & end calls Recent calls **3-way calls** Your phone number **Emergency calls**



Dial contacts, recent calls or numbers, all from one app.

Find it: 📞 Phone

- To call a contact or recent call, tap it.
- To open the dial pad, tap 🗰. Enter a number, then tap 📞 to call it.
- To search your contacts, tap Q and enter a name or number, then tap the contact to call it.



Tips & tricks

- During a call: your touchscreen goes dark to avoid accidental touches. To wake it up, move it away from your face or press the Power button.
- Multi-task: while you're on a call, tap Home O to hide the call screen and look up a phone number, address or open other apps. To reopen the call screen, swipe down the status bar and tap **Ongoing call**.
- · Contacts: to view your contacts, tap CONTACTS.
- Favourite contact: do you have someone you call all the time? Touch and hold an empty spot on your Home screen, tap WIDGETS, then touch and hold the Direct dial widget. Drag it to your Home screen, then select the contact. Tap the widget to dial the person.
- Voicemail: appears in the status bar when you have new voicemail. To hear it, tap \checkmark Phone \rightarrow \blacksquare , then touch and hold 1.

Make calls

Hold

St. Add caller

When you make a call, you have options:

- Tap L Phone, to see your recent calls, favourites and frequently called contacts. Select a contact or number to call it.
- To dial a number, tap 🛄, enter a number, then tap 📞 to call it.
- To enter the international dialling code (+), touch and hold **0**. To add a pause or wait after numbers, tap Menu .

Menu

Back







Calls

Calls Quick start: calls Make calls Answer & end calls Recent calls 3-way calls Your phone number Emergency calls

Menu

More

Answer & end calls

• Answer a call: when your phone is unlocked, tap & ANSWER.

Note: when your phone is locked, swipe right to answer a call.

With call waiting on, tap 🕔 and drag to 📞 to answer the new call, then tap **On hold** or caller's name/number.

- Ignore a call: when your phone is unlocked, tap X REJECT. If locked, swipe left to send the call to voicemail. You can also press the Power button to ignore the call or press a volume button to silence the ringer.
- **Respond with a text:** to send a pre-set message to an incoming caller, tap the caller's name (if visible). Tap () and drag to **=**.
- End a call: tap 😨
- During a call: tap 🖉 Mute to mute the call. To hide the call screen, tap Home O. To reopen it, swipe down the status bar and tap Ongoing call.

Note: when you hold your phone to your ear, the touchscreen goes dark to avoid accidental touches. When you move your phone away from your ear, the screen lights up again.

Don't use covers or screen protectors (even clear ones) that cover the proximity sensor.

Recent calls

View your calls (with newest first), and then call, text or store them:

Find it: \mathbf{V} Phone \rightarrow RECENTS

- To call a number, tap a contact name, then tap CALL BACK.
- To send a text message, store the number or other options, tap the contact picture.
- To remove an entry from the call log, tap it, then tap
 DETAILS →
- To clear the list, tap Menu ♦ → Call history, then tap Menu ♦ → Clear call log.

3-way calls

During a call, you can start another call, switch between them or join them in a 3-way call:

• To answer a second call, tap 🕲 and drag to 📞. To ignore it, tap 🕲 and drag to 🦰.

The first call goes on hold if you answer the second call. To switch between calls, tap the caller's name/number. Tap **On hold** to put a call on hold.

- To dial a second call, tap \clubsuit^{+} , enter a number, then tap \clubsuit to call it.

The first call goes on hold when you tap \clubsuit . To join the calls after the second call answers, tap \clubsuit .



Calls

Calls Quick start: calls Make calls Answer & end calls Recent calls 3-way calls Your phone number Emergency calls

Your phone number

Find it: Apps (iii) \Rightarrow (iv) Settings \Rightarrow About phone \Rightarrow Status \Rightarrow SIM Status \Rightarrow My phone number

Note: may not be available in all countries.

Emergency calls

Note: your service provider programs one or more emergency phone numbers that you can call under any circumstances, even when your phone is locked. Emergency numbers vary by country. Your pre-programmed emergency number(s) may not work in all locations and sometimes an emergency call cannot be placed due to network, environmental or interference issues.

- 1 Tap **C** Phone (if your phone is locked, drag . up to unlock it, then tap **Emergency call**).
- 2 Enter the emergency number.
- **3** Tap **\$** to call the emergency number.

Note: your phone can use location-based services (GPS and AGPS) to help the emergency services find you. See "Location Services" in your Legal Guide.

Henu Menu

Back





Contacts you can be a people person

Contacts Quick start: contacts Create contacts Call, text or email contacts Favourites Edit, delete or hide contacts Get contacts Share contacts My details

Menu

Back


More

Quick start: contacts

Combine information from your Google™ contacts and social networks for quick access to everyone you know.

Find it: Apps → 🔼 Contacts

- Create: tap 🕙
- Edit or delete: tap a contact, then tap 🎤.
- Call, text or email: tap a contact, then tap an option.



Tips & tricks

- Search contacts: from the Home screen, tap the Google search box and enter a contact's name. Or, in the Contacts list, tap Q_{\bullet} .
- Send contacts: tap a contact, then tap Menu → Share to send it in a message, email or via Bluetooth, Google Drive[™] or Android Beam[™].
- Shortcuts: tap a contact, then tap Menu → Place on Home screen to add a shortcut for this contact on your Home screen.
- Synchronise: on your phone, tap Apps (iii) → ¹/₂ Settings. Go to the Accounts section, choose your Google account, then tap your account name to sync it if it has not recently been updated. You can also see these contacts at www.gmail.com.

For help with transferring contacts, learn about Motorola Migrate in "**Old phone to new phone**" or go to www.motorola.com/TransferContacts.

Create contacts



Tap a text box to type the name and details. When you're finished, tap \leftarrow Add new contact at the top.

Note: to import contacts or change where they're stored, see "**Get contacts**".

Contacts

Contacts Quick start: contacts Create contacts Call, text or email contacts Favourites Edit, delete or hide contacts Get contacts Share contacts Mv details

	/lenu
--	-------

Back



More 💽 Next >>

Call, text or email contacts Find it: Apps (iii) > Contacts

Tap a contact to see more options. Depending on the information you have for that person, you can call, text or send email. You can also use voice recognition (see "**Speak**").

Favourites

Set your most-used contacts as favourites, so you can get to them faster.

- To set a favourite, tap Apps (iii) → Contacts, select a contact and tap ☆.
- To see your favourites, tap Apps (iii) → Contacts → FAVOURITES.

Edit, delete or hide contacts

Find it: Apps 🔅 > 🔁 Contacts

- To edit a contact, tap it, then tap 🆍. Tap a field to edit it. Tap 🤦 to choose the contact's picture.

Contacts from social networks will be hidden if you select **Delete**. To view these contacts, or delete them permanently, use the social network's app or website.

• To hide the contacts from an account in your **Contacts** list, tap Menu • • **Contacts to display**. Tap an account type to

show it. Tap $\ensuremath{\text{Customise}}$ to deselect accounts you always want to hide.

Get contacts

Get all your contacts in one place.

- To add your social networking contacts, tap Apps 📖
- → Settings → Accounts, then tap + Add account.

Note: you'll need a social networking app first. See "Google Play^{TM"} to get apps.

• To add your email contacts, see "**Email**".

Tip: if you add a **Corporate Sync** account, you can send messages to your co-workers, even if you don't have them stored in your contacts.

- To import contacts from your SIM card (if it didn't happen automatically): tap Apps (...) → Contacts → Menu → Import/export → Import from SIM card. Tap OK to confirm.
- To import contacts from your computer, upload the contacts to your Google™ account at http://contacts.google.com. On your phone, tap Apps (...) → Contacts → Menu

→ Accounts → Menu → Auto-sync data. You can also see these contacts at http://mail.google.com.

For help with transferring contacts, see "**Old phone to new phone**".



Contacts

Contacts **Quick start: contacts Create contacts** Call. text or email contacts Favourites Edit, delete or hide contacts Get contacts Share contacts My details

Share contacts

Share a contact with a Bluetooth connection, in a message or using Google Drive™:

Find it: Apps 📖 → 🔼 Contacts

To share a contact, tap it, then tap Menu ⇒ Share and choose how you want to send it.

Note: you can't share your social network contacts.

My details

Find it: Apps (...) > 2 Contacts

To store your user profile, tap Set up my profile under ME at the top of the contact list.





Next



Messages Quick start: messages Read, forward & more Set your default messaging app Email Chat using Hangouts™

Quick start: messages

Stay in touch with messages and pictures.

Find it: Apps → **■** Messaging

• Create: tap 🛋

- Attach: when you're typing a message, tap 📎 to attach a picture, video or other file.
- Send: tap > to send the message.



Tips & tricks

- Forward a message: in a conversation, touch and hold a message for more options, such as forwarding it.
- Save pictures: touch and hold a picture to save it. To see the picture, tap Apps (....) → S Gallery.
- Voice entry: just tap a text box, then tap \oint on the keyboard.

Tip: If you don't see ♥ on the keyboard, tap Apps (III) → I Settings → Language & input → Google voice typing to activate voice entry.

• Text your best friend: use a widget to text your favourite contact quickly: touch and hold an empty spot on the Home screen, tap WIDGETS, touch and hold Direct message to drag it to your Home screen, then choose a contact.

Read, forward & more

Find it: Apps 🔅 > 🧮 Messaging

- **Open:** tap a conversation to open it.
- Attachments: when you open a message with an attachment, tap the attachment to open it, or touch and hold it to save it.
- **Reply:** open a conversation, then enter your response in the text box at the bottom.
- Copy, Forward or Delete: open a conversation, touch and hold the message you want, then tap an option. To delete a whole thread of messages, open the thread, then tap Menu → Delete thread.

Back



Messages

Messages Quick start: messages Read, forward & more Set your default messaging app Email Chat using Hangouts™ • Settings: tap Menu • → Settings to change your notifications and other options.

Set your default messaging app

You can also use $\mathsf{Hangouts^{\mathsf{TM}}}$ to send and receive your text messages.


To set **Q** Hangouts or **Messaging** as your default messaging app:

Find it: Apps $\textcircled{\baselineskip}$ \Rightarrow $\textcircled{\baselineskip}$ Settings \Rightarrow More \Rightarrow Default SMS app

For more about Hangouts, see "Chat using Hangouts™".

Email

Send and receive email. Set up and manage accounts. Find it: Apps $\textcircled{m} \rightarrow M$ Gmail



• Add Gmail accounts: the first time you turned on your phone, you probably set up or logged in to your Google™ account — that sets up the **M Gmail** app for one account.

To add more Google accounts, tap Apps $(:::) \Rightarrow (:) \Rightarrow$





Messages

Messages Quick start: messages Read, forward & more Set your default messaging app Email Chat using Hangouts™

Menu Rack



Add email accounts: the Gmail app manages all of your email accounts. To add personal email accounts, follow the prompts when you first open the M Gmail app, or tap Apps (iii) ⇒ ¹/₁₀ Settings → Accounts, then tap + Add account → Email. For Microsoft® Exchange server work email accounts, tap + Add account → Exchange, and enter details from your IT administrator.

- Change account settings: to change Gmail™ account settings, tap Apps (...) → (2) Settings → Accounts → Google.
- Delete accounts: to delete a Gmail or email account, tap the account name, then tap Menu [•] → Remove account.
- Switch accounts: to quickly switch between your email accounts, tap , and tap your other account at the top.

Chat using Hangouts[™]

Sign in with your Google account to stay in touch with friends and family.

Find it: Apps → 👽 Hangouts

- Start a new hangout: tap +, then tap a name in your list of friends. You can send a text message, or tap **I** to make a video call.
- Change settings: tap = to see your old hangouts, change your profile pic, other settings and more.
- Chat from a computer: you can chat from a computer, too. Find out more at www.google.com/hangouts.



Type Quick start: type Text entry settings & dictionary Cut, copy & paste

Menu

Back

More

Quick start: type

When you tap a text box, like in a message or search, you have keyboard options.

• **Type or gesture:** enter letters by touching them one at a time. Or, enter a word by tracing a path through the letters.

See a different

for texting.

keyboard? It varies

by app. This one is

• Close the keyboard: tap ∇ .



Tips & tricks

- Move the cursor: tap a spot in the text to place the cursor, then drag the arrow under the cursor to move it.
- Dictionary: to add a word you enter often, enter it, tap the word in the word list below the text box, then tap there again to add it to your dictionary.
- **Symbols:** touch and hold a letter to enter the small number or symbol at the top of it.

To enter several numbers or symbols, tap 1123.

- Double letters: circle a letter to enter two of them.
- Capital letters: tap 🛧 or drag it to the letter you want to capitalise.
- **Special characters:** touch and hold a letter to choose from other special characters.
- Word prediction: while you're typing, word suggestions appear above the keyboard. Tap one to select it.
- Voice entry: tap \P on the touchscreen keyboard, then say what you want to type. You can speak as long as you like, pause whenever you want and dictate punctuation.
- Vibrate: don't like the vibrating keys when you type? Tap Apps (iii) → 🏟 Settings → Language & input → Google Keyboard → Preferences.



Туре

Type Quick start: type Text entry settings & dictionary Cut, copy & paste

Text entry settings & dictionary

Choose your keyboard style and edit the dictionary of words your phone suggests:

Find it: Apps () → 🏟 Settings → Language & input

- To choose your touchscreen keyboard, tap Current keyboard. To allow voice entry from the keyboard, tap Google voice typing.
- To change the preferences for your keyboard, tap **Google keyboard**.
- To add or edit the words that your phone suggests and recognises, tap **Personal dictionary**.

Cut, copy & paste

Cut, copy and paste names, phone numbers, addresses, quotes or anything else in a text box.

1 To highlight a word, touch and hold it.

To highlight more words, drag the selector at the edge of the highlight.

2 Tap the icons to cut or copy.

Tip: touch and hold icons to show labels.

- **3** Open the text box where you want to paste the text (even if it's in a different app).
- **4** Tap in the text box, then touch and hold to show the **PASTE** option. Tap **PASTE** to paste the text.

H Menu

Back





Organise

get it done any time

Organise Clock Calendar Corporate sync Office network Google Drive™ Print

Clock

Find it: Apps $\textcircled{\baselinetwidth} \Rightarrow \textcircled{\baselinetwidth} Clock \Rightarrow \textcircled{\baselinetwidth}$

• Alarm: tap (). Tap an alarm to edit it, or tap 📀 to add a new alarm.

Tip: pressing the volume button up or down while you're setting an alarm sets the volume level for that alarm.

When an alarm sounds, tap ($^{\textcircled{o}}$) and drag to \bigotimes to turn it off, or drag to $\mathbf{Z}^{\mathbf{z}'}$ to snooze for ten minutes.


- Settings: to change your alarm volume, snooze delay or other settings, tap Menu • Settings.
- World clock: for other time zones, tap 🌐.
- Timer: for a timer, tap **X**.
- Stopwatch: for a stopwatch, tap $\dot{(}^{\dagger})$

Tip: to find out what an icon means, touch and hold it. To set your current date, time, time zone and formats, tap Apps (...) → (2) Settings → Date & time.

Calendar

See all your events, all in one place.





- Change the view: tap the month at the top to choose a date to view. Or tap Menu to choose Schedule, Day or 5 Day.
- Go to today's date: tap 📩.
- Add events: tap a time on the calendar and tap •. Enter event details, then tap SAVE.







Organise

Organise Clock Calendar Corporate sync Office network Google Drive™ Print

Menu



- Show, edit or delete events: tap an event to open it, then tap edit *i*. Tap **DELETE** to remove the event.

Tip: add a **Calendar** widget to your Home screen. Touch and hold an empty spot on the Home screen, tap **WIDGETS**, then touch and hold the **Calendar** widget.

Corporate sync

If you use Microsoft® Office Outlook on your work computer, your phone can synchronise email, events and contacts with your Microsoft Exchange server.

- To add your Corporate account, see "Email".

Office network

To connect your office network with a Virtual Private Network connection, see "Virtual Private Networks (VPN)".

Google Drive[™]

Keep all your photos, videos, documents and more safely in one place — private unless you choose to share. Available on Google Drive from all your devices.



- To create a new file or folder, tap 😶.
- To open a file, tap it.
- To edit a document, tap anywhere in the text to begin typing.

Print

To print your photos, documents and more from your phone, check to see if your printer's manufacturer has an app on Google Play. Then tap Apps (:::) → 🏟 Settings → Printing to get started.

You can also send your photos, docs and more to any Android device in your cloud or to Google Drive. Just download the Cloud Print app from Google.



Google AppsTM Google PlayTM Google NowTM Google+TM

Google Play™

Google Play is a digital content experience from Google where you can find and enjoy your favourite films, books, magazines and Android apps and games.

- Download apps: tap Apps (...) → 🝺 Play Store.
- Find out more about **Google products:** see www.google.com/about/products.
- Log in or open a **Google account:** visit www.google.com/accounts.
- Google help: see www.google.com/support.
- Access all of your files in the cloud: check out "Your cloud".


Google Now™

Google Now brings you just the right information at just the right time, before you even ask. Weather, traffic, public transport timetables, even the latest scores come automatically, appearing throughout the day just as you need them.

To get started, touch and hold Home \bigcirc , then swipe up to the Google icon .

To turn Google Now on/off, set your preferences or learn more, open Google Now, tap \blacksquare \Rightarrow Settings.

Tip: when Google Now is on, swipe right from the Home screen to see it.



Google+™

Google+ makes connecting on the web more like connecting in the real world. Share your thoughts, links and photos with the right circles.

Find it: Apps : → 8 Google+







Google Apps[™]

Google AppsTM Google PlayTM Google NowTM Google+TM

- Upload photos: tap Apps (iii) → **E** Gallery and tap a photo or video. Choose < → Google+ and select your account.
- Add a widget: use a widget to quickly read your Google+ posts. Touch and hold an empty spot on the Home screen, tap WIDGETS, then touch and hold Google+ posts to drag it to your Home screen.
- Help: for more about Google+, visit www.google.com/+.
- Other social networks: you can also use Facebook®, Twitter and more. Open Google Play to find the latest official apps and widgets.



Back		






Browse Quick start: Chrome™ Web connection Downloads Browser options Safe surfing & searching

Quick start: ChromeTM Find it: Apps (....) → O Chrome

- Go to a webpage: tap the address bar at the top of a page and enter an address.
- Add a bookmark: open the address bar (drag down if you don't see it), then tap Menu $\Rightarrow \frac{1}{\sqrt{2}}$.
- Open a bookmark: open the address bar, then tap Menu → Bookmarks.



Tips & tricks

- Webpage shortcut: to add a shortcut to a webpage on your Home screen, when viewing the webpage, tap Menu → Add to Home screen.
- Internet search shortcut: in the Home screen, tap the Google search box at the top and enter a website address.

Note: if you can't connect, contact your service provider.

- Mobile sites: some websites automatically show you a "mobile" version of their page — if you want to see the standard computer versions of all websites, tap Menu
 Request desktop site.
- **Reload:** if a page doesn't load correctly, tap Menu $\Rightarrow \mathbb{C}$.
- Tabs: to open a new tab, tap Menu → New tab. If you have more than one browser page open, tap Overview to move from one to another.
- Clear history: in the browser, tap Menu [•] → Settings → Privacy → CLEAR BROWSING DATA. Then choose history, cache, cookies and other options.
- Help: for more about Google Chrome, tap Menu → Help & feedback or visit www.supportgoogle.com/chrome.

Web connection

To access the web, your phone uses your Wi-Fi network (or your mobile phone network if no Wi-Fi network is connected).

Note: your service provider may charge to surf the web or download data over your mobile phone network.

To connect to a Wi-Fi network, see "Wi-Fi networks".





Browse

Browse Quick start: Chrome™ Web connection Downloads Browser options Safe surfing & searching

Downloads

Warning: apps downloaded from the web can be from unknown sources. To protect your phone and personal data from theft, download apps only on Google Play™.

To download a file, picture or webpage, tap Apps 📖

- \rightarrow **(O)** Chrome and go to the website:
- Files: tap the download link. To show the file or app, tap Apps (:::) → ③ Downloads.
- Pictures: touch and hold it to choose Save image. To see the picture, tap Apps (...) → S Gallery → Download.

To download apps or phone updates, see "**Download apps**" or "**Update your phone**".

Browser options

To change your browser security settings, text size and other options, tap Menu \clubsuit \Rightarrow **Settings**.

Safe surfing & searching

Keep track of what your browser and searches show:

- Incognito: to open a tab that won't appear in your browser or search history, tap Apps (...) → O Chrome → Menu → New Incognito tab.
- Clear history: to clear your browser history and other saved information, tap Apps (...) → ○ Chrome → Menu → Settings → Privacy → CLEAR BROWSING DATA.
- Auto-complete: when you enter your name in an online form, your browser can automatically enter your address information. If you don't want that, tap Apps (:::)

→ \bigcirc Chrome → Menu \vdots → Settings → Auto-fill forms, then tap the switch at the top to turn it off.

• Pop-ups: to stop pop-up windows from opening, tap Apps (iii) → ② Chrome → Menu → Settings → Content settings → Block pop-ups.

B Menu





Photos & videos


see it, capture it, share it!

Photos & videos Quick start: photos & videos Take photos Record videos The perfect shot View, share & use photos & videos Capture your screen

Quick start: photos & videos

With two twists of the wrist and a tap on the screen, take crisp, clear photos with the 21 megapixel camera.

- Launch it: even when your phone is asleep, open your camera with two twists of your wrist.
- See it: swipe left for your photo gallery (🖪 Gallery).
- **Share it:** view a photo or video from your gallery, then tap Share <



Tips & tricks

- Quick Capture: tap Apps (iii) → **O** Camera, swipe the screen right and tap **1** to turn Quick Capture on or off. When Quick Capture is on, twist your wrist twice to open the camera.
- Take a selfie: tap () in the camera screen or twist your wrist twice to switch to the front camera.
- **Record a video:** tap (a) in the camera screen to temporarily switch to the video camera and start recording. Then tap (a) to stop recording.
- Capture a still shot during a video: tap anywhere on the screen while recording to save a photo.
- Change settings: to open camera options, swipe the camera screen right. Rotate the dial to see more options.
- **Zoom:** drag the camera screen up or down using one finger.
- **Multi-shot:** when you're ready, touch and hold the camera screen to take a burst of photos.
- **Panorama:** to take a panoramic shot, swipe the camera screen right to open settings, then tap . Use the on-screen guide to slowly pan your phone.
- Crop: to edit a photo, tap the photo to select it, then tap /.
- Print: want to print your photos? Check out "Print".

Back



Photos & videos

More

Next



Photos & videos Quick start: photos & videos Take photos Record videos The perfect shot View, share & use photos & videos Capture your screen

Menu

Back

Take photos

Find it: Apps ::: → **○** Camera

Tap anywhere on the camera screen to take the photo.

Record videos

Find it: Apps $\textcircled{\baselinetwidth} \rightarrow \textcircled{\baselinetwidth} \mathbf{Camera}$, then tap $\textcircled{\baselinetwidth}$

The camera temporarily turns into a video camera and immediately starts recording. Tap () to stop recording.

Tip: to send a video in a text message, swipe the camera screen left to open your gallery, tap the video, then choose to share.

The perfect shot

Point, tap and you're done. But when you want something a little different, play with these camera options.

Tip: to open camera options, swipe the camera screen right. Rotate the dial to see more options.

Options	
HDR ^Ø HDR	Turn on HDR (high dynamic range) effect for better pictures in challenging lighting situations, such as outdoors.
🗗 Flash	Set On, Off or Auto .

Options	
Control focus and exposure	Drag the brackets over the object you want to focus on (turns green when in focus). Tap the screen to take the photo. Slide the dial around the circle to adjust the exposure.
Night mode	Take photos in low-light situations.
Video 🕬	Take a Full HD, SloMo or Ultra HD (4K) video.
🛄 Photo	Take a Widescreen or Standard photo.
([†]) Timer	Set a timer to 3 seconds or 10 seconds.
Panorama	Take a wide-angle shot. Use the on-screen guide to slowly pan while you are taking the photo.
Storage	Choose storage location of your photos and videos (Phone or SD card).
Location	Tag your photos with a location.
 Shutter sound 	Turn the shutter sound on or off.
\lambda Quick Capture	Twist your wrist twice to turn the camera on. Twist twice again to switch to front camera.

Photos & videos

More



Photos & videos Quick start: photos & videos Take photos Record videos The perfect shot View, share & use photos & videos Capture your screen

B Menu



View, share & use photos & videos Find it: Apps (iii) → S Gallery

• Play, share or delete: tap a thumbnail to open it, then choose < to share, 🝵 to delete or Menu 🕯 for more.

Tip: to select multiple files, open a folder, touch and hold a photo, then tap others.

• Zoom: open a photo in your gallery, then drag two fingers apart or together on the screen.

Tip: Turn your phone sideways for a landscape view.

- Wallpaper or contact photo: open a picture, then tap Menu → Set picture as.
- Edit: open a picture, then tap 🎤.
- Slideshow: tap a picture, then tap Menu → Slideshow. To stop the slideshow, tap the screen.

Tip: to show the slideshow on a television or other device, see "**Connect & transfer**".

Capture your screen

Share a screen capture of your favourite playlist, your new high score or a friend's contact information. If you can show it on your phone, you can share it with your friends.

To capture your phone's screen, press and hold both the Power button and the Volume down key at the same time.

To see the screen capture, tap Apps $(ii) \rightarrow \mathbf{\overline{S}}$ Gallery $\rightarrow \mathbf{\overline{S}}$ Screenshots.



Play Films & TV



films & programmes, wherever you go

Play Films & TV Quick start: Play Films & TV YouTube™

Quick start: Play Films & TV

Find and rent films and TV programmes to watch on your phone, tablet or computer:

To shop, rent or watch on a computer, go to **www.google.com/play** and choose "Films & TV".

YouTube™

Watch videos from YouTube users everywhere — or log in to your account to share your own.

Find it: Apps : → ▶ YouTube







Play Music Quick start: music

Quick start: music

Music everywhere — stream it, buy it, save it, play it. Listen and create playlists any time.

Note: you can buy music only in the US and some countries.

Find it: Apps → 🎧 Play Music

To upload your music library to Google Play Music™, from a computer, visit **www.google.com/music.**

Tap Listen Now to see recommendations and more.



Tips & tricks

- Volume: press the volume buttons.
- Hide the music player: to use another app while your music plays, tap Home O. To return to the music player, swipe the status bar down and tap the song title.

Tip: you can also select **Next**, **Pause** or **Previous** by swiping down the notification bar or using the controls on your unlock screen.

- Home screen: control music playback from the Home screen by adding the **Google Play Music** widget.
- **Playlists:** tap Menu next to a song in your library to add it to a playlist or show other options. To edit, rename or delete a playlist, touch and hold its name in the music library.
- Download your music library for offline listening: To download, tap next to a song, artist, album or playlist. To listen offline, tap , then Downloaded only to avoid using data to stream your music library.
- **During a flight:** Aeroplane mode lets you listen to your offline music and disconnects all connections. Swipe down the status bar with two fingers and tap **Aeroplane mode** to turn it on.
- File types: your phone can play MP3, M4A, AAC, AAC+, MIDI and WAV files.
- Radio: for FM radio, plug in a headset or earbuds, then tap Apps (iii) → FM Radio.

Note: copyright — do you have the right? Always follow the rules. See **"Content Copyright"** in your legal and safety information.

Menu



Locate & navigate

where you are, where you're going

More

Nex

Locate & navigate Quick start: locate & navigate

Menu

Back


Quick start: locate & navigate

Find a nearby cafe, get directions or step-by-step GPS voice navigation using the Google Maps[™] you know and trust.

Find it: Apps → 🎇 Maps

Enter what you want to find in the search bar, then tap it to see more information and options.

Note: your map screen may look different.



Tips & tricks

- Find an address: in the search field, enter an address or something you're looking for, such as "restaurant". The map moves to show the address or local suggestions. Tap the address info at the bottom for more details.
- Get directions: enter a place or address, then tap 📀.
- Save an address: tap the address info at the bottom of the screen and then tap SAVE.
- Zoom: to zoom in or out, drag two fingers together or apart on the screen.
- **Turn and tilt:** rotate two fingers on the map to turn it, or drag down/up to tilt.
- Share a location: tap a location, then tap the address at the bottom of the screen and tap Share.
- **Identify address:** touch and hold a spot on the map to show the nearest address.




More

wired up or wireless

Connect & transfer Quick start: connect & transfer Bluetooth® wireless Wi-Fi networks USB cables Share your data connection Data usage NFC Your cloud Phone & tablet Memory card Virtual Private Networks (VPN) Mobile network Aeroplane mode


Menu

Back



Connect accessories, computers, networks and more.

Find it: Apps ::: → 🏟 Settings



Tips & tricks

- Quick settings: get to the most used settings quickly. Swipe down the status bar with two fingers. See "Quick settings".
- Bluetooth® devices: to connect a Bluetooth headset, keyboard or other device, tap Bluetooth.
- Wi-Fi networks: to connect, tap Wi-Fi.
- Wi-Fi hotspot: to make your phone a hotspot, check out "Wi-Fi hotspot".
- USB cable: your phone's micro USB port lets you exchange media and other files with a connected computer. To change the type of USB connection, tap Apps (:::)

→ Settings → Storage → Menu → USB computer connection.

- Automatic connections: when Bluetooth or Wi-Fi power is on, your phone automatically reconnects to available devices or networks it has used before.
- Aeroplane mode: need to shut down wireless connections quickly? Swipe down the status bar with two fingers and tap Aeroplane mode.
- **Print:** want to print your photos, docs or other things? Check out "**Print**".



Connect & transfer Quick start: connect & transfer Bluetooth® wireless Wi-Fi networks USB cables Share your data connection Data usage NFC Your cloud Phone & tablet Memory card Virtual Private Networks (VPN) Mobile network Aeroplane mode

]] Menu

More

Bluetooth® wireless

Turn Bluetooth power on/off

Find it: Apps (:::) \rightarrow (2) Settings \rightarrow Bluetooth, then tap the switch to turn it on

Note: swipe down the status bar with two fingers to quickly turn Bluetooth on or off.

Tip: to extend battery life or stop connections, turn Bluetooth off when you're not using it.

Connect devices

The **first time** you connect a Bluetooth device, follow these steps:

- 1 Make sure the device you are pairing with is in discoverable mode (for details, refer to the guide that came with the device).
- 2 Tap Apps : → 🏟 Settings → Bluetooth.
- **3** Make sure the switch is on.
- **4** Tap a found device to connect it (if necessary, tap **Pair** or enter a passkey such as **0000**).

Tip: Tap 🎝 to rename a device.

When the device connects, the Bluetooth status indicator is shown at the top of the screen

To automatically **disconnect** or **reconnect** a device anytime, like a wireless headset, just turn the device off or on.

Note: using a mobile device or accessory while driving may cause distraction and may be illegal. Always obey the law and drive safely.

Manage devices

To manually reconnect your phone with a paired device, tap the device name in the list.

To manually disconnect your phone from a paired device, tap the device name in the devices list, then tap **OK**.

To remove a paired device, tap 🏠 next to the device name, then tap **Unpair**.

To change the name your phone shows to other devices, tap Apps $(iii) \Rightarrow (iii) \Rightarrow (iii) \Rightarrow Rename phone.$ Enter a name and tap RENAME.

Let devices find your phone

To let a Bluetooth device discover your phone, just turn the Bluetooth switch on.

Transfer files

- Photos or videos: open the photo or video, then tap << → Bluetooth.

More



Connect & transfer Quick start: connect & transfer Bluetooth® wireless Wi-Fi networks USB cables Share your data connection Data usage NFC Your cloud Phone & tablet Memory card Virtual Private Networks (VPN) Mobile network Aeroplane mode

Menu

Find it: Apps (iii) → 🏟 Settings → Wi-Fi, then tap the switch to turn it on

Connect to networks

Turn Wi-Fi power on/off

Wi-Fi networks

To find networks in your range:

1 Tap Apps : → 🏟 Settings → Wi-Fi.

Tip: to show your phone's MAC address and Wi-Fi settings, tap Menu \Rightarrow **Advanced**.

- 2 Make sure the Wi-Fi switch is turned on.
- 3 Tap a found network to connect to it (if necessary, enter Network SSID, Security and Wireless password, and tap Connect).

When your phone connects, the Wi-Fi status indicator 💎 appears in the status bar.

Note: If you see a question mark in the Wi-Fi status indicator **?**, swipe the status bar down, tap the network and enter the network's password.

Tip: when Wi-Fi is on, your phone automatically reconnects to available networks it has used before. If a router previously had no Internet connection, your phone will not automatically connect to it.

Wi-Fi hotspot

Note: this phone supports apps and services that may use a lot of data, so make sure your data plan meets your needs. Contact your service provider for details.

You can make your phone a Wi-Fi hotspot to provide portable, convenient Internet access to other Wi-Fi enabled devices.

Note: keep it secure. To protect your phone and hotspot from unauthorised access, it is strongly recommended that you set up hotspot security (WPA2 is the most secure), including password.

Find it: Apps (iii) \Rightarrow (iii) Settings \Rightarrow More \Rightarrow Tethering & mobile hotspot and tick Mobile Wi-Fi hotspot

Note: these steps may vary depending on your network.

- 1 Your phone turns off Wi-Fi and uses the mobile network for Internet access. Tap **Set up Wi-Fi hotspot** to set up security:
 - Network name: enter a unique name for your hotspot.
 - Security: select the type of security you want: None or WPA2 PSK. For WPA2 PSK, enter a unique password that others will need to access your Wi-Fi hotspot.
 - **Password**: create a password with at least eight characters.

2 Tap SAVE.

When your Wi-Fi hotspot is active, other Wi-Fi enabled devices can connect by entering your hotspot's **Network name**, selecting a **Security** type and entering the correct **Wireless password**.



Connect & transfer Quick start: connect & transfer Bluetooth® wireless Wi-Fi networks USB cables Share your data connection Data usage NFC Your cloud Phone & tablet Memory card Virtual Private Networks (VPN) Mobile network Aeroplane mode

Menu



USB cables

Note: copyright — do you have the right? Always follow the rules. See **"Content Copyright"** in your Legal Guide.

To load music, pictures, videos, documents or other files from your computer, connect your phone to your computer with a USB cable. To change the type of USB connection (if necessary), tap Apps (:::) → 🏟 Settings → Storage → Menu 🚦 → USB computer connection.

Tip: make sure you connect the phone to a high power USB port. Typically, these are located directly on your computer.

Note: the first time you use a USB connection, your computer may indicate that drivers are being installed. Follow any prompts you see to complete the installation. This may take a few minutes.

- For Microsoft® Windows®: on your computer, choose Start, then select Windows Explorer from your list of programs. In Windows Explorer, your phone will appear as a connected drive (mass storage device) where you can drag and drop files, or it will appear as an MTP or PTP device that lets you use Windows Media Player to transfer files. For more instructions or driver files, visit www.motorola.com/support.
- For Apple[™] Macintosh[™]: use Android File Transfer, available at **www.android.com/filetransfer**.

Share your data connection

Your computer can access the Internet through your phone's mobile network — you just need a USB cable.

Tip: to share a Wi-Fi connection, see "Wi-Fi hotspot".

- 1 Connect your phone to your computer using a USB cable.
 - **Note:** if your computer is running something older than Microsoft® Windows® 7 or Apple™ Macintosh™ OSX, it might require special configuration.
- 2 On your phone, tap Apps (iii) → 🏟 Settings, then make sure the Wi-Fi switch is set to off.
- 3 In Settings, tap More → Tethering & mobile hotspot, then check USB tethering to start the connection.

To stop the connection, deselect **USB tethering**, then disconnect your phone from your computer.

Data usage

You can track the amount of data your phone uploads and downloads.

Find it: Apps $\textcircled{m} \rightarrow \textcircled{a}$ Settings \rightarrow Data usage



Connect & transfer Quick start: connect & transfer Bluetooth® wireless Wi-Fi networks USB cables Share your data connection Data usage NFC Your cloud Phone & tablet Memory card Virtual Private Networks (VPN) Mobile network Aeroplane mode

Menu

Back





Your phone shows a data usage graph. Below the graph, apps appear in order of highest to lowest data usage. Apps that use a lot of data might also use a lot of battery power.



Note: usage information is provided to help you manage your phone. This may not match the amounts charged by your service provider, as they're not measured in the same way.

NFC

Near Field Communication technology lets you instantly share content (such as web links, contacts and photos), information and more, by touching the back of your phone to another NFC-enabled device.

Share with Android Beam™

Use Android Beam to share content on your phone with another NFC-enabled phone or tablet.

Note: the other device must support NFC, too.

- **1** Open the screen that contains the map page or browser page you want to share.
- **2** Touch the back of your phone to the back of the other device.

When the devices connect, you'll see **Touch to beam** on your phone.

3 Touch your screen to share your content.

Receive with NFC

Receive web links, e-coupons, brochures, maps and more from an NFC tag. Look for the NFC logo on posters, signs, store displays and other areas. Just touch the back of your phone to the logo to receive its tag information.

Bluetooth & Wi-Fi one-touch setup

Just touch your phone to an NFC-enabled Bluetooth device or Wi-Fi access point to automatically pair or connect with the device.

Mobile payment

You can use any secure payment app to pay for your purchase (where available).



Connect & transfer Quick start: connect & transfer Bluetooth® wireless Wi-Fi networks USB cables Share your data connection Data usage NFC Your cloud Phone & tablet Memory card Virtual Private Networks (VPN) Mobile network Aeroplane mode

Menu



Look for the NFC logo to confirm that you can make a mobile payment. Touch the back of your phone to the payment device to pay for your purchase.

Security

Mobile payments, wireless connections and content sharing all demand security:

- **Range:** NFC only works over a short range (about 4 cm/1.5 inches), so it's unlikely you'll connect by mistake if you did, you would still have to accept the connection to send or receive information.
- **Encryption:** your phone uses the latest security, encryption and authentication features to protect your personal information for mobile payments and content sharing.

Your cloud

One account with access to everything, everywhere — phone, tablet, computer.

Sync your Google account

When you log in to the same Google account, all devices can get to all the same apps, contacts, films, books and music from Google Play — plus you share the same Gmail, Google Calendar™ and Google Mobile™. To add accounts to your phone, tap Apps (iii) → 🏟 Settings → Accounts, then tap 🕂 Add account → Google.

Phone & tablet

Your Android[™] phone and tablet can work together to help you get the most out of both:

- Transfer media and files: copy files to your phone and transfer them to other devices see "Transfer files".
- Phone hotspot: if you have a Wi-Fi tablet, turn your phone into a Wi-Fi hotspot to let your tablet access the Internet anywhere — see "Wi-Fi hotspot".
- Bluetooth® accessories: if you have a Bluetooth keyboard or other accessories to use with your tablet, remember you can use them with your phone too. To connect them, see "Bluetooth® wireless".

Memory card

Your photos, videos and other files are automatically stored in your phone's internal memory. You can set certain apps, such as the camera, to store files on a microSD card.

Note: Your phone supports memory cards up to 128 GB.

Find it: Apps $\textcircled{m} \rightarrow \textcircled{s}$ Settings \rightarrow Storage \rightarrow SD card

Mount or unmount memory card

To mount a memory card, simply put it into your phone (see "**Put in the cards & power on**").

To unmount your memory card (so you can take it out of your phone), tap Apps $(\textcircled{iii}) \Rightarrow \textcircled{o}$ Settings \Rightarrow Storage \Rightarrow Unmount SD card.



Connect & transfer Quick start: connect & transfer Bluetooth® wireless Wi-Fi networks USB cables Share your data connection Data usage NFC Your cloud Phone & tablet Memory card Virtual Private Networks (VPN) Mobile network Aeroplane mode



More 🕻 Next > **Caution:** do not remove a memory card while your phone is using it or writing files to it.

Erase memory card content

To delete all the information (music, photos and files) from your memory card, tap Apps (:::) → 🏟 Settings → Storage → Erase SD card.

Virtual Private Networks (VPN)

A VPN lets you access files on a secured network (such as an office network with a firewall). Contact the network administrator to ask for VPN settings and any additional apps or other requirements.

To enter VPN settings, tap Apps (:::) \Rightarrow (::) \Rightarrow VPN. Tap \rightarrow to add a new VPN. Choose the type of VPN and enter settings from the network administrator. The network is stored in the VPN list so you can select it whenever you need to connect.

Mobile network

You should not need to change any network settings. Contact your service provider for help.

To see network settings options, tap Apps $\textcircled{iii} \Rightarrow \textcircled{a}$ Settings \Rightarrow More \Rightarrow Mobile networks.

Aeroplane mode

Use aeroplane mode to turn off all your wireless connections — useful when flying. Swipe down the status bar with two fingers, then tap **Aeroplane mode**.

Note: when you select aeroplane mode, all wireless services are disabled. You can then turn Wi-Fi and/or Bluetooth® power back on, if permitted by your airline. Other wireless voice and data services (such as calls and text messages) remain off in aeroplane mode. Emergency calls to your region's emergency number can still be made.



Protect keep your phone safe

Protect Quick start: protect your phone Screen lock Screen pinning Encrypt your phone Back up & restore Reset Stolen phone?

Quick start: protect your phone


Make sure your information is protected in case your phone is lost or stolen.

Find it: Apps (...) → 🏟 Settings → Security

The easiest way to protect your phone is to use **Screen lock**. You can choose to swipe to unlock (less secure), or enter a pattern, PIN or password to unlock your phone.

Screen lock

To keep your phone secure, you can make the touchscreen lock when it goes to sleep.



Find it: Apps $(iii) \Rightarrow (iii) \Rightarrow$ Settings \Rightarrow Security \Rightarrow Screen lock, then select the lock type:

- None: turn off the screen lock.
- Swipe: tap 🛈 and drag up.
- Pattern: draw a pattern to unlock.
- PIN: enter four to sixteen digits to unlock.
- Password: enter four to 16 letters, digits or symbols to unlock.

To change when your touchscreen goes to sleep, tap Apps (ⅲ) → � Settings → Display → Sleep.

Note: you can make emergency calls on a locked phone (see "**Emergency calls**"). A locked phone still rings, and you do not need to enter a PIN or password to answer a call.

Can't unlock?

Pattern, PIN or password: if you forget your pattern, PIN or password, you can enter your Google™ account email and password to unlock the phone.

If you don't have a Google account on your phone, contact your service provider to have your device factory reset.

Warning: a factory reset will delete all data on your phone.

Screen pinning

Need to keep an important screen handy, such as a boarding pass or shopping voucher? Pin the screen for easy access.

To set up screen pinning, tap Apps (iii) → 🏟 Settings → Security → Screen pinning.







Protect Quick start: protect your phone Screen lock Screen pinning Encrypt your phone Back up & restore Reset Stolen phone?

] Menu



To pin a screen, open the app you want to pin, tap Overview \square and scroll up. Tap (*).

To unpin the screen, tap Back \triangleleft and Overview \square at the same time.

Encrypt your phone

Caution: if you forget your encryption code, you cannot recover the data stored on your phone or memory card. Encrypting your files can take an hour or more. Leave your phone plugged in and be careful not to interrupt the process.

Encryption protects the accounts, settings, apps and files on your phone, so that people cannot access them if your phone is stolen.

You shouldn't need to use this feature, but to encrypt your phone and require a PIN or password whenever you turn on your phone, tap Apps $\textcircled{}{} \Rightarrow \textcircled{}{} \Rightarrow \textcircled{}{} \text{Settings} \Rightarrow \text{Security} \Rightarrow \text{Encrypt}$ phone.

Back up & restore

Find it: Apps (:::) \Rightarrow (iii) \Rightarrow Settings \Rightarrow Backup & reset, then tap the switch to turn it on

Your Google account data is backed up online. If you reset or replace your phone, just log in to your Google account to restore the contacts, events and other details you synced with the account.

To choose what syncs with the account, tap Apps (...) → 🏠 Settings → Accounts → Google, tap your Google account

and tick what you want to sync.

Note: text messages, call logs and items stored on your phone will not be restored. To restore your Google Play Store apps, see **"Take care of your apps**".

Reset

To reset your phone to factory settings and erase all the data on your phone, tap Apps (:::) \Rightarrow (::) \Rightarrow Settings \Rightarrow Backup & reset \Rightarrow Factory data reset \Rightarrow RESET PHONE.

Warning: all downloaded apps and user data on your phone will be deleted. Data in the cloud will not be deleted.

Stolen phone?

Your phone has Android Device Manager. You can remote lock or reset your device to protect your device from thieves. For details, see **www.google.com/android/devicemanager**.



Want more? Get help & more

Get help & more

Get answers, updates and info:

- Help is here: tap Apps (iii) > **?** Help to get walk-through tutorials, how-tos, FAQs or chat with people who can help, right on your phone.
- Everything Moto X Play: get PC software, user guides and more at www.motorola.com/mymotoxplay.
- Accessories: get accessories for your phone at www.motorola.com/mobility.
- Get apps: Tap Apps (iii) → iii Play Store to buy and download apps.
- News: here's how to find us:
- PouTube™ www.youtube.com/motorola
- Facebook[™] www.facebook.com/motorola
- Twitter www.twitter.com/motorola
- 8 Google+™ www.google.com/+Motorola/posts

Tips

- Interactive: to get started quickly, tap Apps (:::) → **?** Help for interactive tutorials.
- Google help: in almost every Google app, you can tap Menu → Help. You can also view the Google Help Centres online at www.google.com/support.

Crash recovery

In the unlikely event that your phone stops responding to touches and button presses, try a reboot — press and hold the Power button until the screen goes dark and your phone restarts.

Service & repairs

If you have questions or need assistance, we're here to help.

Go to **www.motorola.com/support**, where you can select from a number of customer care options. You can also contact the Motorola Customer Support Centre on 0870-9010-555 (UK) 1850-909-555 (Ireland).





More	
Next	>:

Copyright & trademarks

Motorola Mobility LLC 222 W. Merchandise Mart Plaza 16th Floor Chicago, IL 60654 USA

www.motorola.com

Note: do not ship your product to the above address. If you need to return your product for repairs, replacement or warranty service, please contact the Motorola Customer Support Centre at:

www.motorola.com/support

Certain features, services and applications are network-dependent and may not be available in all areas; additional terms, conditions and/or charges may apply. Contact your service provider for details.

All features, functionality and other product specifications, as well as the information contained in this guide, are based upon the latest available information and believed to be accurate at the time of printing. Motorola reserves the right to change or modify any information or specifications without notice or obligation.

Note: the images in this guide are examples only.

MOTOROLA and the Stylised M Logo are trademarks or registered trademarks of Motorola Trademark Holdings, LLC. Android, Google and other trademarks are owned by Google Inc. The Android robot is reproduced or modified from work created and shared by Google and used according to terms described in the Creative Commons 3.0 Attribution Licence, All other product or service names are the property of their respective owners. © 2015 Motorola Mobility LLC. All rights reserved.

Caution: Motorola does not take responsibility for changes/modification to the transceiver. Product ID: Moto X PLAY

Manual number: 68017970003-A

Menu

Back

